

Copyright © 2003, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

UNITED STATES GOVERNMENT LEGEND

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, SuperStack, and Transcend are registered trademarks of 3Com Corporation. The 3Com logo and CoreBuilder are trademarks of 3Com Corporation.

Intel and Pentium are registered trademarks of Intel Corporation. Microsoft, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation. Novell and NetWare are registered trademarks of Novell, Inc. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company, Ltd.

Netscape Navigator is a registered trademark of Netscape Communications.

JavaScript is a trademark of Sun Microsystems

All other company and product names may be trademarks of the respective companies with which they are associated.

ENVIRONMENTAL STATEMENT

It is the policy of 3Com Corporation to be environmentally-friendly in all operations. To uphold our policy, we are committed to:

Establishing environmental performance standards that comply with national legislation and regulations.

Conserving energy, materials and natural resources in all operations.

Reducing the waste generated by all operations. Ensuring that all waste conforms to recognized environmental standards. Maximizing the recyclable and reusable content of all products.

Ensuring that all products can be recycled, reused and disposed of safely.

Ensuring that all products are labelled according to recognized environmental standards.

Improving our environmental record on a continual basis.

End of Life Statement

3Com processes allow for the recovery, reclamation and safe disposal of all end-of-life electronic components.

Regulated Materials Statement

3Com products do not contain any hazardous or ozone-depleting material.

Environmental Statement about the Documentation

The documentation for this product is printed on paper that comes from sustainable, managed forests; it is fully biodegradable and recyclable, and is completely chlorine-free. The varnish is environmentally-friendly, and the inks are vegetable-based with a low heavy-metal content.

Contents

About this Guide

| | |
|-----------------------------|----|
| Intended Audience | v |
| Conventions..... | v |
| Related Documentation | vi |
| Customer Support..... | vi |

1 Introduction

| | |
|-----------------------------------|-----|
| System Components | 1-1 |
| Chassis | 1-2 |
| Management Options | 1-3 |
| First Time Startup Interview..... | 1-3 |
| Configuration Tool | 1-3 |

2 Installation

| | |
|---------------------------------|-----|
| Before You Start | 2-1 |
| Site Requirements | 2-2 |
| Shipment Check | 2-2 |
| Additional Equipment..... | 2-4 |
| Required Equipment | 2-4 |
| Tools..... | 2-4 |
| Cables | 2-4 |
| Terminal or PC..... | 2-5 |
| Chassis Rack Installation | 2-5 |
| Front Rack Mounting | 2-5 |
| Tabletop Mounting | 2-6 |

3 Interface Connections and First Time Start-Up

| | |
|--|-----|
| Making Connections | 3-1 |
| Management Serial Port Connections | 3-1 |
| Connecting a Terminal or PC to the System Front Serial Craft Port | 3-2 |
| Connecting Remotely..... | 3-3 |
| Power Connections | 3-3 |
| Startup and Normal Operation LED Displays | 3-4 |
| POST Error Beep Codes | 3-5 |
| First Time Startup..... | 3-7 |

| | | |
|----------|--|------|
| 4 | <i>Configuring the Security Switch 6200 System</i> | |
| | Configuring System Parameters..... | 4-2 |
| | Configuring User Accounts | 4-5 |
| | Configuring the Network Time Protocol (NTP) | 4-6 |
| | Configuring Domain Name Resolution..... | 4-6 |
| | Configuring the Simple Network Management Protocol (SNMP) | 4-7 |
| | Configuring Physical Interfaces..... | 4-10 |
| | Configuring Tap Interfaces | 4-12 |
| | Configuring Network Interfaces | 4-13 |
| | Configuring IP Aliases | 4-14 |
| | Configuring Static Routes | 4-16 |
| | Configuring Static ARP Entries..... | 4-17 |
| | Configuring the Virtual Router Redundancy Protocol (VRRP)..... | 4-18 |
| | Exiting from the Configuration Tool | 4-21 |
| | Saving Your System Configuration | 4-21 |
| | Restoring Your System Configuration..... | 4-21 |
| | Displaying Your System Configuration..... | 4-21 |
| | Restoring the system to Factory Default Settings..... | 4-25 |
| | Getting Help Within the Configuration Tool | 4-25 |
| 5 | <i>Upgrading the System Software</i> | |
| | Upgrading the System Software | 5-1 |
| 6 | <i>Upgrading the System Software Using the Safe Upgrade and Rollback Features</i> | |
| | Using Multiple Versions of Software (Safe Upgrade)..... | 6-1 |
| | Upgrading from Version 2.0 | 6-1 |
| | Upgrading from Version 2.1 and Greater | 6-3 |
| | Upgrading from Software to a UP While an RP is Operational (Rollback)..... | 6-4 |
| 7 | <i>Technical Support</i> | |
| | Online Technical Services | 7-1 |
| | World Wide Web Site | 7-1 |
| | 3Com Knowledgebase Web Services | 7-2 |
| | 3Com FTP Site..... | 7-2 |
| | Support from Your Network Supplier | 7-2 |
| | Support from 3Com | 7-3 |
| | Email Support | 7-3 |
| | Telephone Support | 7-3 |
| | Returning Products for Repair..... | 7-6 |
| A | <i>Technical Specifications</i> | |
| | Physical Characteristics..... | A-1 |
| | Environmental Characteristics..... | A-1 |
| | Power Characteristics | A-1 |

B Connector Pin Assignments

C Regulatory Information

| | |
|---|-----|
| Regulatory Standards Compliance | C-1 |
| CE marking for the EEA (European Economic Area) | C-1 |
| Safety | C-1 |
| Factory Approvals | C-1 |
| EMI Compliance | C-2 |
| Radio Frequency Interference | C-2 |
| VCCI Statement V-3/2000.04 | C-2 |
| Other EMI Approvals | C-2 |
| Immunity Compliance | C-2 |



About this Guide

This guide describes how to install and configure the 3COM Security Switch 6200 hardware and system software. The Security Switch 6200 is based on the 3COM system software and may be referred to as the system.

Intended Audience

This guide is intended for system integrators and other qualified service personnel responsible for installing, configuring, and managing the system.

Conventions

The following conventions are used throughout this guide to emphasize certain information, such as, user input, screen options and output, and menu selections.

italics – Indicates book titles and user input variables.

`Courier` – Indicates user input and program output.

Courier italics – Indicates variables in commands.

Menu => – Indicates to select an Option from the menu pull-down.

Warnings, Cautions, and Notes indicate the following:

NOTES – Provide helpful suggestions or reference to materials not contained in this manual.



WARNING:

Warnings notify you to proceed carefully in order to avoid personal harm.



CAUTION:

Cautions notify you to proceed carefully in order to avoid damaging equipment or losing data.

**Related
Documentation**

The following guides provide additional installation and configuration information for the system.

Security Switch 6200 Product Release Notes

Install Server Installation and Configuration Guide

Security Switch 6200 Applications Guide

**Customer
Support**

To obtain technical tips or support, refer to the Technical Support chapter of this guide.

The Security Switch 6200 is a high performance, turnkey security services switch that integrates best-in-class firewall, virtual private networks, intrusion detection, and content security engines. The system offers high port density, high availability, and simplicity of management in a compact, expandable form factor.

The system is a Network Processor-based security platform that provide exceptional performance while maintaining flexibility for security application support. The system's unique flow management and acceleration technology enables simultaneous processing of traffic by multiple services.

The system is used by medium to large enterprises to consolidate the functions of multiple appliances at a fraction of the cost.

This chapter describes the system components.

System Components

The system has a compact, expandable form factor and is either rack or table-top mountable. The system provides the following features:

- Fixed 16-10/100 Ethernet and 2-fiber or copper Gigabit Ethernet (GE) interfaces.
- Network Interface Module (NIM) powered by the Network Processor.
- Dual-processor motherboard (Application Module) with high-speed Pentium III processors.
- High-speed Ethernet backplane connecting the network and application processing modules.
- 40 GB hard drive.
- Two out-of-band 10/100 Ethernet management ports.
- Two USB ports (may be used for modem support).

- One serial console port.
- Two redundant, hot-swappable power supplies.
- Five expansion slots for optional VPN or other security acceleration cards.

Chassis

The chassis is front rack mountable, in a standard 19 inch rack.

Figure 1-1 displays the 6200 system's major components.




Figure 1-1 6200 Front View

Figure 1-2 displays the rear panel components.

NOTE: This figure is shown for reference only. The console connections should be made from the 6200 front panel, with the management connections taking place in the rear of the chassis.




Figure 1-2 Rear Panel Component Layout

Management Options

The system provides two system management options:

- First time startup interview
- Configuration Tool

First Time Startup Interview

The system uses a built in, easy to configure, interview tool (cos_interview) that allows you to quickly configure your system for basic operations. For further information on the startup interview, refer to the *Interface Connections and First Time Start-Up* chapter of this guide.

Configuration Tool

The system uses a menu driven configuration interface (cos_config) for configuration purposes. This tool supports adding, modifying, or deleting any of the system configuration parameters. For further information on this tool, refer to the *Configuring the System* chapter of this guide.

2

Installation

This chapter describes the system installation, covering the following topics:

- Pre-installation considerations
- Chassis installation
- Interface connections

Before You Start



WARNING:

To ensure power connectivity, if you are using more than one power supply, be sure to use separate power sources.

Before installing your system, be sure that the site's environmental and space requirements allow optimal chassis access and operation. In addition, you need to verify that you have the equipment and the tools necessary to complete this installation.

Site Requirements

The system installation site should meet the following requirements:

| Requirement | Description |
|-----------------------|---|
| Operating Temperature | 0 to 40 degrees C |
| Relative Humidity | 10% - 90%, non-condensing |
| Minimum Ventilation | 6 inches (15.2 cm) to the front, back, and sides of the chassis |
| Service Clearance | 30 inches (76.2 cm) at the front of the chassis |
| Power Sources | 100 to 240 VAC outlets, with grounding and power surge protection |
| Rack | Standard 19-inch rack with grounding |

Shipment Check

Using the packing slip as a reference, inspect package contents for missing or damaged items. If parts are missing or damaged, call your 3COM Systems Support Representative (Refer to Chapter 5, for contact information.). The following items, as a minimum, are included with your system:

- Chassis
- Mounting screws
- Rubber feet
- Two power cables
- One serial console port cable
- CDs containing the system software, product documentation, and applications
- Warranty card

Figure 2-1 shows the standard shipping contents:




Figure 2-1 3COM Security Switch 6200 Shipping Contents

NOTE: 3COM recommends that you save the shipping containers in the event you need to send back one or more components.

Additional Equipment

- PC running RedHat Linux 6.2 or greater software. This software is used to support the Security Switch 6200 Graphical User Interface (GUI) and for hosting the Check Point™ FireWall-1® Management Server.
- PC running WinNT4/Win2K software. This software is used for launching the Check Point FireWall-1 GUI and the system's embedded WEB GUI.
- Security applications licenses to activate installed software on the system.

Required Equipment

To install the chassis in a standard rack you need certain hand tools, appropriate cabling, and additional hardware not included in the chassis shipment.

Tools

To install the chassis into a standard rack you need, as a minimum, a Phillips screwdriver (9" minimum, #2).

Cables

Cabling requirements are installation-specific. Prior to installation you should know:

- The kind and number of cables required for each type of interface.
- The distance limitations for each signal type. Table 2-1: provides the approximate cable distance limitations.

Table 2-1: Cable Distance Limitations

| Cable Description | Distance Limitation |
|---|---|
| Craft port: RS-232 DB9 directly from the system | 15 meters maximum (50 feet maximum) |
| Management Link port: 10/100 | Cat 5 cable, 100 meters (328 feet) |
| Copper Ethernet Link Port: 10/100/1000 | Cat 5 cable, 100 meters (328 feet) |
| Fiber Ethernet Link Port: Gigabit | 62.5 micro-fiber - 275 meters (902 feet) 50 micro-fiber - 550 meters (1805 feet) |

Table 2-2: shows the cables that ship with chassis.

Table 2-2: System Cables

| Cable | Description |
|---------------|--|
| Power Cabling | Standard AC power cable. |
| Console Port | Serial shielded straight-through 9-pin D-sub female to 9-pin male cable. |

Terminal or PC

A VT-100 terminal or a Personal Computer (PC) is required during installation. The terminal or PC is connected to the chassis's craft port, allowing you to monitor start-up diagnostics and to configure the unit for remote management access.

Chassis Rack Installation

The chassis can be installed in the front or center of a standard 19" rack.

Front Rack Mounting

To install the chassis in the front of your rack:

1. Remove the center brackets (one on each side) from the system.
2. Position the chassis in the rack by aligning the holes on its integrated front mounting brackets with the holes in the rack.
3. Insert the appropriate screws through the brackets and tighten. If the rack holes are not threaded, use cage-nuts over them. Figure 2-2 shows a chassis installation example.





Figure 2-2 Front Rack Mounting the Chassis

Tabletop Mounting

The system can be mounted on any desk or table top. To do this you first need to attach the four rubber feet, supplied with the system, to the bottom of the box. To do this, complete the following:

1. Turn the system over onto its top with the bottom facing up.
 2. Locate the indented feet locators, as shown in the following figure.
-



3. Peel backing off of the rubber feet and press them down firmly on the indents.

Once the rubber feet are installed you can mount the system on a solid flat surface.

3

Interface Connections and First Time Start-Up

This chapter describes the procedure for powering up the system for the first time. Specifically covered are the following:

- Connecting to the Management Console
- Powering Up the System
- First time configuration

Making Connections

This section describes connections to the chassis interfaces, including:

- Management serial port
- Ethernet port
- Power connections

Management Serial Port Connections

The system provides you with multiple ways to access the Management Console. You can connect to the console by either connecting a terminal or a PC to the system's serial (craft) connector or by Telneting into the system Management Console remotely.

For the initial configuration you can connect to the system through the craft port. Alternatively, you can connect to the system through telnet if you have the DHCP service in your network. By default, DHCP is enabled on your system, after your initial configuration you can disable the DHCP service.

To connect to the serial connector use the DB9 serial connector located on the front panel of the system.

NOTE: If you are connecting to the system Management Console using a terminal or PC, the serial port on the terminal or PC must be configured for 9600 baud, 8 data bits, 1 stop bit, no parity, and no flow control.

Connecting a Terminal or PC to the System Front Serial Craft Port

To connect a terminal or PC to the system front serial craft port:

1. Connect one end of a DB9-to-DB9 cable into the terminal or PC.
2. Connect the other end into the system serial craft port. Figure 3-1 shows the system connected to a laptop computer.




Figure 3-1 Connecting a Laptop Computer to the system Front Serial Craft Port

3. Set to VT-100 terminal emulation mode.

Connecting Remotely

To access the system remotely:

1. Connect one end of an RJ45-to-RJ45 cable into a remote access device.
2. Connect the other end into the Management port. Figure 3-2 shows the Management port module connected to a hub.




Figure 3-2 Connecting to the System Remotely

3. Telnet to configure IP.

Power Connections

CAUTION: To ensure power connectivity, if you are using more than one power supply, be sure to use separate power sources.

To connect power cabling:

1. Place the female end of the power cable into the power supply connector located on the back of the chassis. Refer to Figure 3-3 for the exact location.




Figure 3-3 System Rear View Power Connections

NOTE: Before applying power to the system, be sure you have connected a terminal or PC to the craft port. This allows you enter commands needed at startup.

2. Attach the male end of the power cable into an AC power source. The system is powered up when power is applied to the power supplies.

NOTE: If the system is powered up with one power supply or if one of the power supplies experiences a loss of power, an audible alarm sounds. To silence this sound, press the red button located on the left side of the primary power supply.

Startup and Normal Operation LED Displays

During power up and normal operation, you can observe start-up activity by checking LED activity on the system front panel.

Table 3-1 describes the various front panel LEDs and their function.

Table 3-1 Front Panel LED Descriptions

| LED | Color/Label | State | Description |
|---|----------------|-----------------------|--|
| 10/100 Fast Ethernet | Green | On | Ethernet connectivity present. |
| | Yellow | Flashing | Traffic is present. |
| 10/100/100 Fast Ethernet/Gigabit Ethernet | Fiber/Green | On | Fiber connectivity present. |
| | Activity/Green | Flashing | Traffic is present. |
| | Link/Green | On | Ethernet connectivity present. |
| Power/Sleep(PWR) | Green | On | Power on. |
| | | Flashing ¹ | In sleep state. |
| | Off | Off | Power is off. |
| MGMT1/MGMT2 | Green | Random Flash | NIC activity present. |
| System Status (SYS) | Green | On | Running with normal operation. |
| | | Flashing ² | Degraded. |
| | Amber | On | Critical or non-recoverable condition. |
| | | Flashing ² | Non-critical condition. |
| | Off | Off | Post/system stop. |
| Disk Activity (HDD) | Green | Random Flash | Disk activity present. |
| | Off | Off ³ | No hard disk activity detected. |

1. The PWR LED sleep indication is maintained on standby by the system. If the system is powered down without going through BIOS, the LED state in effect at the time of power off, is restored when the system is powered on until cleared by the BIOS. If the system is not powered down normally, the PWR LED may blink even though the SYS LED may be off due to a failure or configuration change that prevents the BIOS from running.
2. The Amber status takes precedence over the Green status. When the Amber LED is on or flashing, the Green LED is off.
3. This LED is also off when the system is powered off or in a sleep state.

POST Error Beep Codes

The following tables list POST error beep codes. Before system video initialization, the BIOS and BMC use these beep codes to inform users on error conditions.

BMC Generated POST Beep Codes

| Code | Description |
|---------|--|
| 1-5-1-1 | FRB failure (processor failure) |
| 1-5-2-1 | Empty Processor |
| 1-5-2-2 | No Processor |
| 1-5-4-2 | Power fault: DC power unexpectedly lost (power control failures) |
| 1-5-4-3 | Chipset control failure |
| 1-5-4-4 | Power control failure |

BIOS Generated POST Error Beep Codes

| Beeps | Error message | Description |
|-------|--------------------------------------|--|
| 1 | Refresh timer failure | The memory refresh circuitry on the motherboard is faulty. |
| 2 | Parity error | Parity can not be reset. |
| 3 | Base memory failure | Base memory test failure. See Table 53. POST Memory Error 3-Beep Codes for additional error details. |
| 4 | System timer | System timer is not operational. |
| 5 | Processor failure | Processor failure detected. |
| 6 | Keyboard controller Gate A20 failure | The keyboard controller may be bad. The BIOS cannot switch to protected mode. |
| 7 | Processor exception interrupt error | The CPU generated an exception interrupt. |
| 8 | Display memory read/write error | The system video adapter is either missing or its memory is faulty. This is not a fatal error. |
| 9 | ROM checksum error | System BIOS ROM checksum error. |
| 10 | Shutdown register error | Shutdown CMOS register read/write error detected. |
| 11 | Invalid BIOS | General BIOS ROM error. |

POST Memory Error 3-Beep Codes

| Beep Code | Debug port 80h error Codes | Daignostic LED Decoder | | | | Meanings |
|-----------|----------------------------|-------------------------|-----|-----|-----|---------------------------------------|
| | | G=Green, R=Red, A=Amber | | | | |
| | | Hi | | | Low | |
| 3 | 00h | Off | Off | Off | Off | No memory was found in the system |
| 3 | 01h | Off | Off | Off | G | Memory mixed type detected. |
| 3 | 02h | Off | Off | G | Off | EDO is not supported. |
| 3 | 03h | Off | Off | G | G | First row memory test failure. |
| 3 | 04h | Off | G | Off | Off | Mismatched DIMMs in a row. |
| 3 | 05h | Off | G | Off | G | Base memory test failure. |
| 3 | 06h | Off | G | G | Off | Failure on decompressing post module. |
| 3 | 07h-odh | Off | G | G | G | Generic memory error. |
| | | G | Off | Off | Off | |
| | | G | Off | Off | G | |
| | | G | Off | G | Off | |
| | | G | Off | G | G | |
| | | G | G | Off | Off | |
| | | G | G | Off | G | |
| 3 | 0Eh | G | G | G | Off | SMBUS protocol error. |
| 3 | 0F-FFh | All other combinations. | | | | Generic memory error. |

First Time Startup

The system uses a built in, easy to configure, interview script that allows you to quickly configure your system for basic operations.

Once you have completed this interview, you can use the system Configuration Tool to set additional parameters.

The interview script is launched from the UNIX root prompt. To launch the interview script, complete the following.

NOTE: Within this interview, you can type the initial letter of an option and then press the Tab key to complete the entire string on supported choices. The Enter key is used to select default values.

1. Log into your system as root.

NOTE: The password is admin.

2. Change to the bin directory within admin and list the files within this directory to locate the necessary interview file.

```
[admin@xxxxxx admin]# cd /usr/os/bin
[admin@xxxxxx bin]# ls
```

3. Locate the file cos_interview and execute the following command at the admin prompt:

```
[admin@xxxxxx bin]# ./cos_interview
```

Once the interview is launched, you are presented with an interactive interview. To begin your initial configuration, answer the following questions.

```
=====
                        Welcome to the Configuration Interview

This program is designed to guide you through the
configuration of your system by prompting you with a
series of questions.
=====
```

1. Enter the Hostname.

```
Hostname
=====
```

Enter the system hostname:

2. Enter the System time.

```
System Time
=====
```

The current date and time on this system is Mon Mar 10
13:04:23 EST 2003

Would you like to modify System time <Y or N>[N]: y

Please provide the date in "Mon DD YYYY" format, where
Mon : month in the form Jan, Feb, etc.
DD : day of month (1 - 31),
YYYY: for example 2002

Enter the Date :

3. Define the Time Zone.

Select a time zone based on the location of your system.

The current Time Zone is "*present-time-zone*"

Would you like to Modify the Time Zone <Y or N> [N]: y

Select a continent or ocean.

- 1) Africa
- 2) Americas
- 3) Antarctica
- 4) Arctic Ocean
- 5) Asia
- 6) Atlantic Ocean
- 7) Australia
- 8) Europe
- 9) Indian Ocean
- 10) Pacific Ocean
- 11) Other (Enter GMT offset)

Enter choice <1 - 11>:

Select a country.

- | | | |
|------------------------|---------------------|-------------------------|
| 1)Antigua & Barbuda | 18)Ecuador | 35)Panama |
| 2)Anguilla | 19)Grenada | 36)Peru |
| 3)Netherlands Antilles | 20)French Guiana | 37)St Pierre & Miquelon |
| 4)Argentina | 21)Greenland | 38)Puerto Rico |
| 5)Aruba | 22)Guadeloupe | 39)Paraguay |
| 6)Barbados | 23)Guatemala | 40)Suriname |
| 7)Bolivia | 24)Guyana | 41)El Salvador |
| 8)Brazil | 25)Honduras | 42)Turks & Caicos Is |
| 9)Bahamas | 26)Haiti | 43)Trinidad & Tobago |
| 10)Belize | 27)Jamaica | 44)United States |
| 11)Canada | 28)St Kitts & Nevis | 45)Uruguay |
| 12)Chile | 29)Cayman Islands | 46)St Vincent |
| 13)Colombia | 30)St Lucia | 47)Venezuela |
| 14)Costa Rica | 31)Martinique | 48)Virgin Islands (UK) |
| 15)Cuba | 32)Montserrat | 49)Virgin Islands (US) |
| 16)Dominica | 33)Mexico | |
| 17)Dominican Republic | 34)Nicaragua | |

Enter choice <1 - 49>:

4. Select a region.

- 1) Eastern Time
- 2) Eastern Time - Michigan - most locations
- 3) Eastern Time - Kentucky - Louisville area
- 4) Eastern Time - Kentucky - Wayne County
- 5) Eastern Standard Time - Indiana - most locations
- 6) Eastern Standard Time - Indiana - Crawford County
- 7) Eastern Standard Time - Indiana - Starke County
- 8) Eastern Standard Time - Indiana - Switzerland County
- 9) Central Time
- 10) Central Time - Michigan - Wisconsin border
- 11) Central Time - North Dakota - Oliver County
- 12) Mountain Time
- 13) Mountain Time - south Idaho & east Oregon
- 14) Mountain Time - Navajo
- 15) Mountain Standard Time - Arizona
- 16) Pacific Time
- 17) Alaska Time
- 18) Alaska Time - Alaska panhandle
- 19) Alaska Time - Alaska panhandle neck
- 20) Alaska Time - west Alaska
- 21) Aleutian Islands

Enter choice <1 - 21>:

5. Define the Management Services.

Management Services

=====

Several methods are available for managing your system through the 10/100 Ethernet interface on the host. Select the desired management services.

Enable Telnet Server <disabled, enabled>[enabled]:

Enable FTP Server <disabled, enabled>[enabled]:

Add DNS Lookups <Y or N>[N]:

DNS Server IP Address [0.0.0.0]:

6. Configure the SNMP parameters.

Configure SNMP Network Management <Y or N>[N]:

Enabling SNMP ...

Enable SNMP Network Management <disabled, enabled>
[disabled]:

Enter SNMP Contact []:

Enter SNMP Location []:

The SNMP community string is the access string to permit access to the SNMP protocol. A read-only "ro" or read-write "rw" access may be specified. By default, SNMP community string permits read-only access.

SNMP Communities

=====

| Community | Address | Netmask | Access |
|-----------|-----------|-----------------|------------|
| middle | 10.1.1.22 | 255.255.255.255 | read-write |

Add the SNMP Communities <Y or N>[N]:

7. Configure the individual user accounts.

Accounts Configuration

=====

This section allows you to change your "root" password. Additionally, you can set up accounts for users to log into once the Interview is complete.

Set 'root' Password <Y or N>[Y]:

Additional user accounts can be defined, each with its own username and password.

Add or Modify User Accounts <Y or N>[Y]:

Enter User Name []:

Enter password:

Verify password:

Enable Login Access <disabled, enabled>[disabled]:

Enter Access Level <Guest, Network Operator, Service Operator, Administrator>[Guest]:

The following is an example display showing configured users.

User Accounts

=====

| User Name | Login Access | Access Level |
|-----------|--------------|---------------|
| admin | enabled | Administrator |
| foobar | enabled | Guest |

Add or Modify User Accounts <Y or N>[Y]: n

8. Configure the host interfaces.

Host Interfaces

=====

This section will help you configure interfaces on the Host. The system has two management ports, two GigaBit Ethernet ports, and 16 10/100 ports.

NOTE: At least one management port must be configured on the system.

Enter choice.

- | | |
|---------------------|------------------------|
| 1) fastethernet 1 | 12) fastethernet 12 |
| 2) fastethernet 2 | 13) fastethernet 13 |
| 3) fastethernet 3 | 14) fastethernet 14 |
| 4) fastethernet 4 | 15) fastethernet 15 |
| 5) fastethernet 5 | 16) fastethernet 16 |
| 6) fastethernet 6 | 17) gigabitethernet 17 |
| 7) fastethernet 7 | 18) gigabitethernet 18 |
| 8) fastethernet 8 | 19) management 1 |
| 9) fastethernet 9 | 20) management 2 |
| 10) fastethernet 10 | X) Exit |
| 11) fastethernet 11 | |

Enter choice <1 - 20, X>[X]:

Enter IP Address [0.0.0.0/0]:

9. Configure all additional interfaces.

Continue configuring interfaces <Y or N>[N]:

Enter choice.

- 1) fastethernet 1
- 2) fastethernet 2
- 3) fastethernet 3
- .
- .
- .
- 19) management 1
- 20) management 2
- 21) None

Enter choice <1 - 21>[1]:

Enter IP address and mask :

Continue configuring interfaces <Y or N>[N]:

Continue this step until all interfaces are configured.

10. Configure your default gateway.

Default gateway
=====

This section allows you to configure a default gateway for the system. Please provide an IP address, in dotted decimal format.

Default gateway [0.0.0.0]:

11. Configure NTP to achieve time synchronization.

Synchronizing the system's clock with an accurate source is important for proper correlation of security events. The system uses the Network Time Protocol (NTP) to achieve time synchronization. The IP address of an NTP server must be specified.

NTP Server

=====

Add NTP Server <Y or N>[Y]:

Enter NTP Server IP Address [0.0.0.0]:

=====

Congratulations, you have finished the Interview.

To activate your interview settings, you MUST reboot the system using the following command at the prompt:

```
# reboot
```

Exiting the Interview...

=====

4

Configuring the Security Switch 6200 System

The system uses a menu driven configuration interface (`cos_config`) for configuration purposes. This tool supports adding, modifying, or deleting any of the system configuration parameters.

This configuration interface is launched from the UNIX admin prompt. To launch this tool, complete the following:

1. Log into your system as admin.
username: admin
password: admin
2. Change to the bin directory within admin and list the files within this directory to locate the necessary interview file.

```
[admin@xxxxxx admin]# cd /usr/os/bin  
[admin@xxxxxx bin]# ls
```
3. Execute the file `cos_config` and execute the following command at the admin prompt:

```
[admin@xxxxxx bin]# ./cos_config
```

Once the configuration tool is launched, you are presented with an interactive main menu.

```
Configuration
=====
1) System Parameters
2) User Accounts
3) Network Time Protocol (NTP)
4) Domain Name Service (DNS)
5) Simple Network Management Protocol (SNMP)
6) Physical Interfaces
7) Tap Interfaces
8) Network Interfaces
9) IP Aliases
10) Static Routes
11) Static ARP Entries
12) Virtual Router Redundancy Protocol (VRRP)
X) Exit
```

To begin your configuration, select the desired option from the main menu.

NOTE: Within this configuration tool, you can type the initial letter of an option and then press the Tab key to complete the entire string on supported choices. The Enter key is used to select default values.

Configuring System Parameters

This section describes how to change your system settings. Specifically, how to:

- Change the system host name and domain name
- Change system information
- Change time information
- Enable external access ability

To configure system parameters:

1. Select Option 1 from the main menu.

The present System Configuration is displayed. For example:

```
System
=====
Host Name          helios
Domain Name
Date and Time      Mon Apr 07 15:28:27 EDT 2003
Time Zone
Telnet Server      enabled
FTP Server          enabled
WEB Timeout        20
Default Gateway    192.168.10.1

Would You Like to Modify the System Parameters <Y or
N>[N]:
```

2. To change any of the system parameters enter y, or press the Return key to leave system parameters unchanged.

Enter the System Host Name [*hostname*]:

Enter the System Domain Name []:

Enter the Time [15:28:40]:

Enter the Date [Apr 07 2003]:

Would You Like to Modify the Time Zone <Y or N>[N]:

3. To change the time zone enter y or press the Return key to leave system parameters unchanged.

Select a time zone based on the location of your system.

Select a continent or ocean.

- 1) Africa
 - 2) Americas
 - 3) Antarctica
 - 4) Arctic Ocean
 - 5) Asia
 - 6) Atlantic Ocean
 - 7) Australia
 - 8) Europe
 - 9) Indian Ocean
 - 10) Pacific Ocean
 - 11) Other (Enter GMT offset)
- Enter choice <1 - 11>:

Select a country.

- | | | |
|------------------------|---------------------|-------------------------|
| 1)Antigua & Barbuda | 18)Ecuador | 35)Panama |
| 2)Anguilla | 19)Grenada | 36)Peru |
| 3)Netherlands Antilles | 20)French Guiana | 37)St Pierre & Miquelon |
| 4)Argentina | 21)Greenland | 38)Puerto Rico |
| 5)Aruba | 22)Guadeloupe | 39)Paraguay |
| 6)Barbados | 23)Guatemala | 40)Suriname |
| 7)Bolivia | 24)Guyana | 41)El Salvador |
| 8)Brazil | 25)Honduras | 42)Turks & Caicos Is |
| 9)Bahamas | 26)Haiti | 43)Trinidad & Tobago |
| 10)Belize | 27)Jamaica | 44)United States |
| 11)Canada | 28)St Kitts & Nevis | 45)Uruguay |
| 12)Chile | 29)Cayman Islands | 46)St Vincent |
| 13)Colombia | 30)St Lucia | 47)Venezuela |
| 14)Costa Rica | 31)Martinique | 48)Virgin Islands (UK) |
| 15)Cuba | 32)Montserrat | 49)Virgin Islands (US) |
| 16)Dominica | 33)Mexico | |
| 17)Dominican Republic | 34)Nicaragua | |

Enter choice <1 - 49>:

4. Select a region.

- 1) Eastern Time
- 2) Eastern Time - Michigan - most locations
- 3) Eastern Time - Kentucky - Louisville area
- 4) Eastern Time - Kentucky - Wayne County
- 5) Eastern Standard Time - Indiana - most locations
- 6) Eastern Standard Time - Indiana - Crawford County
- 7) Eastern Standard Time - Indiana - Starke County
- 8) Eastern Standard Time - Indiana - Switzerland County
- 9) Central Time
- 10) Central Time - Michigan - Wisconsin border
- 11) Central Time - North Dakota - Oliver County
- 12) Mountain Time
- 13) Mountain Time - south Idaho & east Oregon
- 14) Mountain Time - Navajo
- 15) Mountain Standard Time - Arizona
- 16) Pacific Time
- 17) Alaska Time
- 18) Alaska Time - Alaska panhandle
- 19) Alaska Time - Alaska panhandle neck
- 20) Alaska Time - west Alaska
- 21) Aleutian Islands

Enter choice <1 - 21>:

5. Define the Management Services.

Enable Telnet Server <disabled, enabled>[enabled]:
Enable FTP Server <disabled, enabled>[enabled]:
Enter WEB Timeout [20]:
Enter Default Gateway [0.0.0.0]:

6. Select option 1 from the main menu to display your changed system parameters. For example:

Enter choice <1 - 12, X>[X]: 1

System

=====

| | |
|-----------------|------------------------------|
| Host Name | helios |
| Domain Name | 3com.com |
| Date and Time | Mon Apr 07 15:29:03 EDT 2003 |
| Time Zone | America/New_York |
| Telnet Server | enabled |
| FTP Server | enabled |
| WEB Timeout | 20 |
| Default Gateway | 192.168.10.1 |

Would You Like to Modify the System Parameters <Y or N>[N]:

7. Enter y to make further changes or press the Enter key to return to the main menu.

Configuring User Accounts

Each system user is defined by the user's name, password, and access level. Collectively, these properties define each user's profile. Login access allows you to login into the unix shell, setting this to disabled allows you to only have WEB access. To configure individual user accounts:

1. Select Option 2 from the main menu.

```
Accounts Configuration
=====
```

Additional user accounts can be defined, each with their own username and password.

```
User Accounts
=====
```

| User Name | Login Access | Access Level |
|-----------|--------------|---------------|
| admin | enabled | Administrator |

Modify the User Accounts <Add, Delete, Modify or eXit>[eXit]:

2. Enter the desired option and make changes as necessary or enter X to return to the main menu. The following is an example of a user being added:

```
Modify the User Accounts <Add, Delete, Modify or
eXit>[eXit]: a
```

```
Enter User Name []: fred
```

```
Enter password:
```

```
Verify password:
```

```
Enable Login Access <disabled, enabled>[disabled]:
enabled
```

```
Enter Access Level <Guest, Network Operator, Service
Operator, Administrator>[Guest]: administrator
```

```
User Accounts
=====
```

| User Name | Login Access | Access Level |
|-----------|--------------|---------------|
| admin | enabled | Administrator |
| fred | enabled | Administrator |

3. Enter the desired option and make more changes or enter X to return to the main menu.

```
Modify the User Accounts <Add, Delete, Modify or
eXit>[eXit]:
```

Configuring the Network Time Protocol (NTP)

The Network Time Protocol (NTP) is used to synchronize the time of a computer client or server to another server or reference time source, such as a radio or satellite receiver or modem. It provides accuracies typically within a millisecond on LANs and up to a few tens of milliseconds on WANs relative to Coordinated Universal Time (UTC) through a Global Positioning Service (GPS) receiver, for example. Typical NTP configurations utilize multiple redundant servers and diverse network paths in order to achieve high accuracy and reliability.

To configure NTP:

1. Select Option 3 from the main menu.

```
NTP Servers
=====
xxx.xxx.xx.x
```

```
Modify the NTP Servers <Add, Delete or eXit>[eXit]:
```

2. Enter the desired option and add or delete an NTP server or enter X to return to the main menu.

Configuring Domain Name Resolution

Domain name resolution allows you translate and search domain names. The Domain Name System (DNS) is a global network of servers that translate host names like www.mycompany.com into numerical IP (Internet Protocol) addresses, for example 24.62.13.19.

To configure domain name resolution:

1. Select Option 4 from the main menu.

```
Domain Name Resolution Configuration
=====
1) DNS Servers
2) DNS Search Domains
X) Exit
```

```
Enter choice <1 - 2, X>[X]: 1
```

2. Enter the desired option. For example:

```
Enter choice <1 - 2, X>[X]: 1
```

```
DNS Servers
=====
```

```
Modify the DNS Server List <Add, Delete or eXit>[eXit]: a
```

```
DNS Server's IP Address [0.0.0.0]: 10.1.1.50
```

```
DNS Servers
=====
```

```
10.1.1.50
```

```
Modify the DNS Server List <Add, Delete or eXit>[eXit]:
```

```
Domain Name Resolution Configuration
=====
1) DNS Servers
```

```

2) DNS Search Domains
X) Exit

Enter choice <1 - 2, X>[X]: 2

DNS Search Domains
=====

Modify the DNS Domain Search List <Add, Delete or
eXit>[eXit]: a

Enter DNS Search Domain []: 3com.com

DNS Search Domains
=====

3com.com

Modify the DNS Domain Search List <Add, Delete or
eXit>[eXit]:

Domain Name Resolution Configuration
=====

1) DNS Servers
2) DNS Search Domains
X) Exit

Enter choice <1 - 2, X>[X]:

```

3. Enter the desired option or enter X to return to the main menu.

Configuring the Simple Network Management Protocol (SNMP)

To configure SNMP:

1. Select Option 5 from the main menu.

```

SNMP configuration
=====

1) SNMP Server
2) Communities
3) Trap Destinations
X) Exit

```

2. Configure SNMP Servers. For example:

```

Enter choice <1 - 3, X>[X]: 1

SNMP Server
=====

Enabled      enabled
Contact      Root <root@localhost> (configure /etc/snmp/
snmp.local.conf)

Location      Unknown (edit /etc/snmp/snmpd.conf)

Would You Like to Modify the SNMP Configuration <Y or
N>[N]: y

Enable SNMP Network Management <disabled,
enabled>[enabled]:

Enter SNMP Contact [Root <root@localhost> (configure /

```

```
etc/snmp/snmp.local.conf)): srhen@crossbeamsys.com
Enter SNMP Location [Unknown (edit /etc/snmp/
snmpd.conf)]: Lab
```

```
SNMP configuration
=====
```

```
1) SNMP Server
2) Communities
3) Trap Destinations
X) Exit
```

```
Enter choice <1 - 3, X>[X]: 1
```

```
SNMP Server
=====
```

```
Enabled      enabled
Contact      lab@3com.com
Location     The Lab
```

```
Would You Like to Modify the SNMP Configuration <y or
n>[n]:
```

3. Enter y to modify the SNMP configuration or n to return to the SNMP Configuration menu.

```
SNMP configuration
=====
```

```
1) SNMP Server
2) Communities
3) Trap Destinations
X) Exit
```

4. Configure SNMP Communities. For example:

```
Enter choice <1 - 3, X>[X]: 2
```

```
SNMP Communities
=====
```

| Community | Address | Netmask | Access |
|-----------|---------|---------|--------|
|-----------|---------|---------|--------|

```
Change the SNMP Communities <Add, Delete or
eXit>[eXit]: a
```

```
Enter Community Name []: foobar
```

```
Enter IP Source Addresses [0.0.0.0/32]: 10.2.1.48/32
```

```
Enter Access Mode <read-only, read-write>[read-only]:
read-write
```



```
SNMP Communities
=====
```

| Community | Address | Netmask | Access |
|-----------|-----------|-----------------|------------|
| foobar | 10.2.1.48 | 255.255.255.255 | read-write |

```
Change the SNMP Communities <Add, Delete or
eXit>[eXit]: a
```

```
Enter Community Name []: public
Enter IP Source Addresses [0.0.0.0/32]: 10.0.0.0/8
Enter Access Mode <read-only, read-write>[read-only]:
```

```
SNMP Communities
=====
```

| Community | Address | Netmask | Access |
|-----------|-----------|-----------------|------------|
| foobar | 10.2.1.48 | 255.255.255.255 | read-write |
| public | 10.0.0.0 | 255.0.0.0 | read-only |

```
Change the SNMP Communities <Add, Delete or
eXit>[eXit]:
```

5. Enter the desired option or enter X to return to SNMP Configuration Menu.

```
SNMP configuration
=====
```

```
1) SNMP Server
2) Communities
3) Trap Destinations
X) Exit
```

6. Configure SNMP Trap Destinations. For example:

```
Enter choice <1 - 3, X>[X]: 3
```

```
SNMP Traps
=====
```

| Destination | Port | Type | Version | Community |
|-------------|------|------|---------|-----------|
|-------------|------|------|---------|-----------|

```
Change the SNMP Trap Destinations <Add, Delete, Modify
or eXit>[eXit]: a
```

```
Enter Trap Destination [0.0.0.0]: 10.2.1.48
Enter Port Number [162]:
Enter Trap Type <trap, inform>[trap]:
Enter SNMP Version <SNMPv1, SNMPv2c, SNMPv3>[SNMPv1]:
Enter Community []: foobar
```

```
SNMP Traps
=====
```

| Destination | Port | Type | Version | Community |
|-------------|------|------|---------|-----------|
| 10.2.1.48 | 162 | trap | SNMPv1 | foobar |

Change the SNMP Trap Destinations <Add, Delete, Modify or eXit>[eXit]:

7. Enter the desired option or enter X to return to SNMP Configuration Menu.

```
SNMP configuration
=====
```

- 1) SNMP Server
- 2) Communities
- 3) Trap Destinations
- X) Exit

8. Enter the desired option or enter X to return to the main menu.

Configuring Physical Interfaces

There are three types of physical interfaces on the system: management, gigabitethernet, and fastethernet. The management interfaces allow you to manage the configured interfaces.

To configure the physical interfaces:

1. Select Option 6 from the main menu.

```
Physical Interfaces
=====
```

| Interface | MAC Address (Configured) | Auto neg | Duplex | Speed |
|-----------------|-----------------------------|-------------|--------|-------|
| management 1 | 00:03:47:f1:aa:52 | (N) on | half | 10 |
| management 2 | 00:03:47:f1:aa:53 | (N) on | half | 10 |
| fastethernet 1 | | (N) on | half | 10 |
| fastethernet 2 | | (N) on | half | 10 |
| fastethernet 3 | | (N) on | half | 10 |
| fastethernet 4 | | (N) on | half | 10 |
| fastethernet 5 | | (N) on | half | 10 |
| fastethernet 6 | | (N) on | half | 10 |
| fastethernet 7 | | (N) on | half | 10 |
| fastethernet 8 | | (N) on | half | 10 |
| fastethernet 9 | | (N) on | half | 10 |
| fastethernet 10 | | (N) on | half | 10 |
| fastethernet 11 | | (N) on | half | 10 |
| fastethernet 12 | | (N) on | half | 10 |
| fastethernet 13 | | (N) on | half | 10 |

| Interface | MAC Address (Configured) | Auto neg | Duplex | Speed |
|--------------------|-----------------------------|-------------|--------|-------|
| fastethernet 14 | | (N) on | half | 10 |
| fastethernet 15 | | (N) on | half | 10 |
| fastethernet 16 | | (N) on | half | 10 |
| gigabitethernet 17 | | (N) on | half | 10 |
| gigabitethernet 18 | | (N) on | half | 10 |

Modify Physical Interface Parameters <y or n>[n]:

- Enter y to modify a physical interface or n to return to the main menu.
For example:

```
Modify Physical Interface Parameters <y or n>[n]: y
Enter the Interface Name [fastethernet 1]:
MAC Address []: 00:00:a2:00:00:01
Auto Negotiate <off, on>[on]: off
Duplex <half, full>[half]: full
Speed <10, 100, 1000, unknown>[10]:
```

Physical Interfaces
=====

| Interface | MAC Address (Configured) | Auto neg | Duplex | Speed |
|--------------------|-----------------------------|-------------|--------|-------|
| management 1 | 00:03:47:f1:aa:52 | (N) on | half | 10 |
| management 2 | 00:03:47:f1:aa:53 | (N) on | half | 10 |
| fastethernet 1 | 00:00:a2:00:00:01 | (Y) off | full | 10 |
| fastethernet 2 | | (N) on | half | 10 |
| fastethernet 3 | | (N) on | half | 10 |
| fastethernet 4 | | (N) on | half | 10 |
| fastethernet 5 | | (N) on | half | 10 |
| fastethernet 6 | | (N) on | half | 10 |
| fastethernet 7 | | (N) on | half | 10 |
| fastethernet 8 | | (N) on | half | 10 |
| fastethernet 9 | | (N) on | half | 10 |
| fastethernet 10 | | (N) on | half | 10 |
| fastethernet 11 | | (N) on | half | 10 |
| fastethernet 12 | | (N) on | half | 10 |
| fastethernet 13 | | (N) on | half | 10 |
| fastethernet 14 | | (N) on | half | 10 |
| fastethernet 15 | | (N) on | half | 10 |
| fastethernet 16 | | (N) on | half | 10 |
| gigabitethernet 17 | | (N) on | half | 10 |

| Interface | MAC Address (Configured) | Auto neg | Duplex | Speed |
|--------------------|-----------------------------|-------------|--------|-------|
| gigabitethernet 18 | | (N) on | half | 10 |

Modify Physical Interface Parameters <Y or N>[N]:

3. Enter y to modify additional physical interfaces or n to return to the main menu.

Configuring Tap Interfaces

Tap interfaces are used to copy the input and output packets from a physical interface prior to the processing by the firewall acceleration process. These taps can be used by intrusion detection software to sniff the interface. Tap interfaces can be given any device name of up to 15 characters, and a single tap can capture the traffic for multiple physical interfaces. To configure Tap Interfaces:

1. Select Option 7 from the main menu.

```
Tap Interfaces
=====
```

```
Name          Physical Interfaces
```

```
Modify the Tap Interfaces <Add, Delete, Modify or
eXit>[eXit]: a
```

2. Enter the desired option to add, delete, or modify a tap interface or enter x to return to the main menu. For example:

```
Tap Name []: tap1
```

```
Physical Interfaces []: fastethernet 1, fastethernet 2,
gigabitethernet 17
```

```
Tap Interfaces
=====
```

```
Name          Physical Interfaces
```

```
tap1 fastethernet 1, fastethernet 2, gigabitethernet 17
```

```
Modify the Tap Interfaces <Add, Delete, Modify or
eXit>[eXit]:
```

3. Enter the desired option to add, delete, or modify additional tap interfaces or enter x to return to the main menu. For example:

```
Tap Name []: tap2
```

```
Physical Interfaces []: fastethernet 3
```

```
Tap Interfaces
=====
```

```
Name          Physical Interfaces
```

```
tap1 fastethernet 1, fastethernet 2, gigabitethernet 17
```

```
tap2 fastethernet 3
```

Configuring Network Interfaces

A network interface associates an IP address with a physical connection and optionally a VLAN id. To configure network interfaces:

1. Select Option 8 from the main menu.

```
IP Interfaces
=====
```

| Enabled | Address | Netmask | Broadcast | MTU |
|--------------|--------------|---------------|----------------|------|
| management 1 | 192.168.10.6 | 255.255.255.0 | 192.168.10.255 | 1500 |
| enabled | | | | |

2. To add a network interface, select add from the main menu.
For example:

```
Modify the IP Interfaces <Add, Delete, Modify or
eXit>[eXit]: a
Physical Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]:
Interface State <disabled, enabled>[enabled]:
Enter the IP Address [0.0.0.0/0]: 128.205.1.23/24
Broadcast Address [128.205.1.255]:
MTU [1500]:
```

```
IP Interfaces
=====
```

| Enabled | Address | Netmask | Broadcast | MTU |
|----------------|--------------|---------------|---------------|------|
| management 1 | 192.168.10.6 | 255.255.255.0 | 192.168.10.25 | 1500 |
| enabled | | | 5 | |
| fastethernet 1 | 128.205.1.23 | 255.255.255.0 | 128.205.1.255 | 1500 |
| enabled | | | | |

3. Enter the desired option to add, delete, or modify additional network interfaces or enter x to return to the main menu. For example:

```
Modify the IP Interfaces <Add, Delete, Modify or
eXit>[eXit]: a
Physical Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]: y Enter VLAN ID <1 - 4095>:
100
Interface State <disabled, enabled>[enabled]:
Enter the IP Address [0.0.0.0/0]: 128.205.2.23/24
Broadcast Address [128.205.2.255]:
MTU [1500]:
```

IP Interfaces

=====

| Enabled | Address | Netmask | Broadcast | MTU |
|---------------------------|--------------------------|---------------|----------------|------|
| management 1 enabled | 192.168.10.6 | 255.255.255.0 | 192.168.10.255 | 1500 |
| fastethernet 1 enabled | 128.205.1.23 | 255.255.255.0 | 128.205.1.255 | 1500 |
| fastethernet 1 enabled | vlan 100 128.205.2.23 | 255.255.255.0 | 128.205.2.255 | 1500 |

Modify the IP Interfaces <Add, Delete, Modify or
eXit>[eXit]:

4. Enter the desired option to add, delete, or modify additional network interfaces or enter x to return to the main menu.

Configuring IP Aliases

IP aliases are additional network addresses that are assigned to a network interface. To configure IP Aliases:

1. Select Option 9 from the main menu.

IP Aliases

=====

| Interface | IP Address | Netmask | Broadcast |
|-----------|------------|---------|-----------|
|-----------|------------|---------|-----------|

Modify the IP Aliases <Add, Delete, Modify or
eXit>[eXit]: a

2. Enter the desired option to add, delete, or modify an IP alias or enter x to return to the main menu. For example:

```
Enter Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]:
Enter IP Address [0.0.0.0]: 128.205.1.24
Enter Network Mask [255.255.0.0]: 255.255.0.0
Enter Broadcast Address [128.205.255.255]:
```

IP Aliases

=====

| Interface | IP Address | Netmask | Broadcast |
|----------------|--------------|-------------|-----------------|
| fastethernet 1 | 128.205.1.24 | 255.255.0.0 | 128.205.255.255 |

Modify the IP Aliases <Add, Delete, Modify or
eXit>[eXit]: m

```
Enter Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]:
Enter IP Address [0.0.0.0]: 128.205.1.24
Enter Network Mask [255.255.0.0]: 255.255.255.0
Enter Broadcast Address [128.205.1.255]:
```

IP Aliases

=====

| Interface | IP Address | Netmask | Broadcast |
|----------------|--------------|-------------|-----------------|
| fastethernet 1 | 128.205.1.24 | 255.255.0.0 | 128.205.255.255 |
| fastethernet 1 | 128.205.1.24 | 255.255.0.0 | 128.205.1.255 |

Modify the IP Aliases <Add, Delete, Modify or
eXit>[eXit]: a
Enter Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]: y
Enter VLAN ID <1 - 4095>: 100
Enter IP Address [0.0.0.0]: 128.205.2.24
Enter Network Mask [255.255.0.0]: 255.255.255.0
Enter Broadcast Address [128.205.2.255]:

IP Aliases

=====

| Interface | IP Address | Netmask | Broadcast |
|----------------|--------------|-------------|-----------------|
| fastethernet 1 | 128.205.1.24 | 255.255.0.0 | 128.205.255.255 |
| fastethernet 1 | 128.205.1.24 | 255.255.0.0 | 128.205.1.255 |
| fastethernet 1 | 128.205.2.24 | 255.255.0.0 | 128.205.2.255 |

vlan 100

Modify the IP Aliases <Add, Delete, Modify or
eXit>[eXit]:

3. Enter the desired option to add, delete, or modify additional IP aliases or enter x to return to the main menu.

Configuring Static Routes

Static IP routes are user-defined routes that cause packets moving between a source and a destination to take a specific path.

To configure Static Routes:

1. Select Option 10 from the main menu.

```
Static Routes
=====
```

| Destination | Netmask | Gateway | Metric |
|-------------|---------|---------|--------|
|-------------|---------|---------|--------|

2. Enter the desired option to add, delete, or modify a static route or enter x to return to the main menu. For example:

```
Modify the Static Routes <Add, Delete, Modify or
eXit>[eXit]: a
Enter Destination [0.0.0.0/0]: 10.0.0.0
Enter Network Mask in dot notation [0.0.0.0]: 255.0.0.0
Enter the Next Hop Gateway [0.0.0.0]: 192.168.10.1
Enter the Metric [1]:
```

```
Static Routes
=====
```

| Destination | Netmask | Gateway | Metric |
|-------------|-----------|--------------|--------|
| 10.0.0.0 | 255.0.0.0 | 192.168.10.1 | 1 |

```
Modify the Static Routes <Add, Delete, Modify or
eXit>[eXit]: a
Enter Destination [0.0.0.0/0]: 192.168.20.0/24
Enter the Next Hop Gateway [0.0.0.0]: 192.168.10.1
Enter the Metric [1]: 2
```

```
Static Routes
=====
```

| Destination | Netmask | Gateway | Metric |
|--------------|---------------|--------------|--------|
| 10.0.0.0 | 255.0.0.0 | 192.168.10.1 | 1 |
| 192.168.20.0 | 255.255.255.0 | 192.168.10.1 | 2 |

```
Modify the Static Routes <Add, Delete, Modify or
eXit>[eXit]:
```

3. Enter the desired option to add, delete, or modify additional static routes or enter x to return to the main menu.

Configuring Static ARP Entries

You define static Address Resolution Protocol (ARP) entries by relating an IP address to a MAC address.

To configure static ARP entries:

1. Select Option 11 from the main menu.

```
Static ARP Entries
=====
IP Address      MAC Address
```

2. Enter the desired option to add, delete, or modify a static ARP entry or enter x to return to the main menu. For example:

```
Modify the Static Hosts <Add, Delete, Modify or
eXit>[eXit]: a
Enter Host IP Address [0.0.0.0]: 128.205.1.30
Enter MAC Address []: 00:00:a2:00:00:02
```

```
Static ARP Entries
=====
IP Address      MAC Address
128.205.1.30    00:00:a2:00:00:02
```

```
Modify the Static Hosts <Add, Delete, Modify or
eXit>[eXit]: a
Enter Host IP Address [0.0.0.0]: 128.205.1.31
Enter MAC Address []: 00:00:a2:00:00:03
```

```
Static ARP Entries
=====
IP Address      MAC Address
128.205.1.30    00:00:a2:00:00:02
128.205.1.31    00:00:a2:00:00:03
```

```
Modify the Static Hosts <Add, Delete, Modify or
eXit>[eXit]:
```

3. Enter the desired option to add, delete, or modify additional static ARP entries or enter x to return to the main menu.

Configuring the Virtual Router Redundancy Protocol (VRRP)

The Virtual Router Redundancy Protocol (VRRP) dynamically assigns responsibility for one or more virtual routers to the VRRP routers on a LAN, allowing several routers on a multiaccess link to utilize the same virtual IP address. The system can be configured to run the VRRP protocol in conjunction with one or more other systems attached to a LAN.

VRRP which manages automatic switchover from one VPN Concentrator to another in a redundant installation. Automatic switchover provides user access to the VPN even if one VPN is out of service for some reason, for example a system crash, power failure, hardware failure, physical interface failure, system shutdown or reboot.

These functions apply only to installations where two or more VPNs are in parallel, with the Public interfaces of all systems on a common LAN and with the Private and/or External interfaces of all systems on different common LANs. One VPN is the Master system, and the others are Backup systems. A Backup system acts as a virtual Master system when a switchover occurs. VRRP works only on LAN (Ethernet) interfaces, not on WAN interfaces.

To configure VRRP:

1. Select Option 12 from the main menu.

```
VRRP Configuration
=====
```

```
Virtual Router Redundancy Protocol can be defined, each
with its own identifier.
```

VRRP Configurations =====

```
VRRP ID : 1
Enabled : disabled
VRRP Interface : fastethernet 1
Enable VRRP MAC : disabled
Preemption : disabled
Priority : 100
Advertisement Interval (seconds) : 1
Group ID : 1
IP Addresses : 30.0.0.10
```

2. Enter the desired option to add, delete, or modify a VRRP entry or enter x to return to the main menu. For example:

```
Modify the VRRP Configuration <Add, Delete, Modify or
eXit>[eXit]: m
Enter VRRP ID [0]: 1
Enable <disabled, enabled>[disabled]: enabled
Enter Interface [fastethernet 1]:
VLAN Interface <Y or N>[N]:
Enable VRRP MAC <disabled, enabled>[disabled]:
Enable Preemption <disabled, enabled>[disabled]:
Enter Priority [100]:
Enter Advertisement Interval (seconds) [1]:
Enter Group ID [1]:
Enter IP Addresses Separated by Comma [30.0.0.10]:
```

VRRP Configurations =====

```
VRRP ID : 1
Enabled : enabled
VRRP Interface : fastethernet 1
Enable VRRP MAC : disabled
Preemption : disabled
Priority : 100
Advertisement Interval (seconds) : 1
Group ID : 1
IP Addresses : 30.0.0.10
```

```
Modify the VRRP Configuration <Add, Delete, Modify or
eXit>[eXit]: a
```

```

Enter VRRP ID [0]: 2
Enable <disabled, enabled>[disabled]:
Enter Interface [management 0]: fastethernet 1
VLAN Interface <Y or N>[N]: y
Enter VLAN ID <1 - 4095>: 100
Enable VRRP MAC <disabled, enabled>[disabled]: enabled
Enable Preemption <disabled, enabled>[disabled]:
Enter Priority [0]: 100
Enter Advertisement Interval (seconds) [1]:
Enter Group ID [0]: 1
Enter IP Addresses Separated by Comma []: 30.0.0.10

```

VRRP Configurations =====

| | |
|----------------------------------|------------------------------|
| VRRP ID | : 1 |
| Enabled | : enabled |
| VRRP Interface | : fastethernet 1 |
| Enable VRRP MAC | : disabled |
| Preemption | : disabled |
| Priority | : 100 |
| Advertisement Interval (seconds) | : 1 |
| Group ID | : 1 |
| IP Addresses | : 30.0.0.10 |
| | |
| VRRP ID | : 2 |
| Enabled | : disabled |
| VRRP Interface | : fastethernet 1 vlan 100 |
| Enable VRRP MAC | : enabled |
| Preemption | : disabled |
| Priority | : 100 |
| Advertisement Interval (seconds) | : 1 |
| Group ID | : 1 |
| IP Addresses | : 30.0.0.10 |

Exiting from the Configuration Tool

To exit from the system Configure Tool, select Option X from the main menu.

```
Enter choice <1 - 12, X>[X]: X
```

Saving Your System Configuration

To save your configuration, at the admin prompt, use the following command:

```
[admin@xxxxxx bin]# ./cos_show_system -f /directory/
filename
```

Where the directory specifies the directory where the file is located, and the filename is the actual configuration file. The following is an example of this command:

```
[admin@helios bin]$ ./cos_show_system -f /tmp/foo
```

Restoring Your System Configuration

To restore your configuration to its previous configuration, at the admin prompt, use the following command:

```
[admin@xxxxxx bin]# ./cos_set_system -f /directory/
filename
```

Where the directory specifies the directory where the file is located, and the filename is the actual configuration file. The following is an example of this command:

```
[admin@helios bin]$ ./cos_set_system -f /tmp/foo
```

Displaying Your System Configuration

To display a configuration, at the admin prompt, use the following command:

```
[admin@xxxxxx bin]# ./cos_show_system
```

The following is an example of this command:

```
[admin@helios bin]$ ./cos_show_system

<system>

<data
hostname="helios"
domainname="3com.com"
timezone="America/New_York"
telnet_server="enabled"
ftp_server="enabled"
gateway="192.168.10.1"
</data>
</system>

<ntp_server>
<data
address="127.127.1.0"
></data>

</ntp_server>
<dns_server>
<data
```

```
address="10.1.1.50"
></data>
</dns_server>

<dns_search>
<data
domainname="3com.com"
></data>
</dns_search>

<snmp_server>
<data
enable="enabled"
contact="lab@3com.com"
location="The Lab"
></data>
</snmp_server>

<snmp_community>
<data
community="foobar"
address="10.2.1.48"
access="read-write"
></data>
<data
community="public"
address="10.0.0.0"
mask="255.0.0.0"
></data>

</snmp_community>
<snmp_trap_destination>
<data
host="10.2.1.48"
community="foobar"
></data>
</snmp_trap_destination>

<physical_interface>
<data
ifname="fastethernet 1"
mac_addr="00:00:a2:00:00:01"
autoneg="off"
duplex="full"
speed="10"
></data>
<data
ifname="fastethernet 15"
autoneg="off"
duplex="half"
speed="100"
></data>
</physical_interface>
```

```
<ip_interface>
<data
ifname="management 1"
address="192.168.10.6"
></data>
<data
ifname="fastethernet 1"
address="128.205.1.23"
mask="255.255.255.0"
></data>
<data
ifname="fastethernet 1"
vlan="100"
address="128.205.2.23"
mask="255.255.255.0"
></data>
</ip_interface>

<ip_alias>
<data
ifname="fastethernet 1"
address="128.205.1.24"
mask="255.255.255.0"
></data>
<data
ifname="fastethernet 1"
vlan="100"
address="128.205.2.24"
mask="255.255.255.0"
></data>
</ip_alias>

<static_route>
<data
destination="10.0.0.0"
mask="255.0.0.0"
gateway="192.168.10.1"
></data>
<data
destination="192.168.20.0"
mask="255.255.255.0"
gateway="192.168.10.1"
metric="2"
></data>
</static_route>

<static_host>
<data
ip_addr="128.205.1.30"
mac_addr="00:00:a2:00:00:02"
></data>
<data
```

```

ip_addr="128.205.1.31"
mac_addr="00:00:a2:00:00:03"
></data>
</static_host>

<account>
<data
username="admin"
shell="enabled"
access_level="Administrator"
></data>
<data
username="foobar"
shell="enabled"
></data>
<data
username="fred"
shell="enabled"
access_level="Administrator"
></data>
</account>

<tap_interface>
<data
tapname="tap1"
ifnames="fastethernet 1, fastethernet 2,
gigabitethernet 17"
></data>
<data
tapname="tap2"
ifnames="fastethernet 3"
></data>
</tap_interface>

<vrrp>
<data
enabled="enabled"
name="fastethernet 1"
id="1"
priority="100"
group_id="1"
ip_addr="30.0.0.10"
></data>
<data
name="fastethernet 1"
vlan="100"
id="2"
use_vmac="enabled"
priority="100"
group_id="1"
ip_addr="30.0.0.10"

```



```
></data>  
</vrrp>
```

Restoring the system to Factory Default Settings

To delete the current configuration and return the system to its factory defaults, use the following command at the admin prompt.

NOTE: The IP address of interface Management 1, telnet, and the default gateway are left in tact. This done in the event you telneted into the box.

```
[admin@xxxxxx bin]$ ./cos_reset_system
```

Getting Help Within the Configuration Tool

To receive help from within the system Configuration Tool, use the following command at the admin prompt.

```
[admin@xxxxxx bin]$ ./cos_show_system --help
```

The following options can be used within this Help system:

```
cos_show_system [OPTION...]  
  
-v, --version - displays the current configuration tool  
version number.  
  
-h, --help - displays the configuration tool's help  
system.  
  
-f, --file=STRING - displays the configuration output  
file. The default value is stdout.  
  
-d, --default - tells the Help system to include  
default values.
```

5

Upgrading the System Software

This chapter describes how to update your 3COM Security Switch 6200 system software.

Upgrading the System Software

If you are upgrading your system from a previously configured release, you do not need to use the full system software. Instead, you can use the software upgrade patch.

NOTE: "upgradepack-ocode-A*-1.0.0-11-2.1.4-17.shar.gz" is the upgrade pack that will enable you to upgrade from 2.1.x to 2.1.4 (x = 0,1,2). To do this, complete the following:

1. Login to your system Console port as Root.
2. Change to the root directory, using the following command:

```
cd /root
```

3. Create a directory, using the following command:

```
mkdir upgradepack-X.X.X-X
```

Where X.X.X-X, is the current software version. For this release X sequence is 2.1.4-17

4. FTP or copy the file called cos-upgradepack-ocode-AZZZ-Y.Y.Y-Y-X.X.X-X.shar.gz from your system Software CDROM or software package to the /root/upgradepack-X.X.X-X.
5. Change the directory to upgradepack-X.X.X-X, using the following command:

```
cd upgradepack-X.X.X-X
```

6. Enter the following command at the root prompt:

```
gzip -d upgradepack-ocode-AZZZ-Y.Y.Y-Y-X.X.X-X.shar.gz
```

7. Once the above command completes, enter the following command at the root prompt:

```
chmod 700 cos-upgradepack-ocode-AZZZ-Y.Y.Y-Y-X.X.X-X.shar
```

8. Once the above command completes, enter the following command at the root prompt:

```
./cos-upgradepack-ocode-AZZZ-Y.Y.Y-Y-X.X.X-X.shar
```

Answer "Y" when this command prompts you.

NOTE: Once this action completes successfully, your system software is upgraded.

You may notice "Exec'ed Program Error" being displayed on your screen during the upgrade process if upgrading from a release prior to 2.1.3. Please ignore these error messages. Your system will still be upgraded properly

9. Reboot your system.

6

Upgrading the System Software Using the Safe Upgrade and Rollback Features

Your system ships with two disk partitions, one partition is used for the current runtime (RP) version of software and the other partition is for the upgraded (UP) version of software. Each partition provides 20 Gigabytes of disk space.

This chapter describes how to update your system software, and how to utilize these partitions.

Using Multiple Versions of Software (Safe Upgrade)

Using two partitions, your system allows you to upgrade your system software while maintaining a previous version of your configuration. The following sections describe how to accomplish this.

Upgrading from Version 2.0

To upgrade your system from Version 2.0 to a newer release, while saving your current configuration, complete the following:

1. Connect to Console port as described in the previous section.
2. Partition your disk for dual boot. Note that this only has to be accomplished once. To do this, from root prompt, enter the following command:

```
fdisk /dev/ataraid/d0
```

3. Within the fdisk command, display a print(p) disk layout by entering the letter “p”. A display similar to the following displays:

```
/dev/ataraid/d0p1 * 1 13 104422 83 Linux  
# /boot
```

```
/dev/ataraid/d0p2 14 79 530145 82 Linux swap
/dev/ataraid/d0p5 80 882 6450097 83 Linux # /
/dev/ataraid/d0p6 883 2070 9542609+ 83 Linux
# /opt
/dev/ataraid/d0p7 2071 2435 2931862 83 Linux
# /var
```

4. Duplicate the above table for the dual boot by entering the letter “n” five times. This adds the following partitions:

Add(n) the following logical(l) partitions in cylinders

| partition | cylinders | partition |
|-----------|-----------|-----------|
| 8 | +12 | /boot |
| 9 | +65 | swap |
| 10 | +802 | / |
| 11 | +1187 | /opt |
| 12 | + | /var |

5. Toggle(t) the swap partition identification from 9 to 82 by entering the letter “t”.
6. Save(w) the partition table by entering the letter “w”.
7. Reboot your system.

You can also perform the software upgrade when you reboot your system using the Install Server. To do this, complete the following:

1. Check to make sure you have the right version of install-cos. To do this:

At root prompt, enter:

```
/usr/os/sbin/install-cos -h
```

The following displays:

```
Usage: /usr/os/sbin/install-cos [OPTION]... <COS
RPM DIR>
```

```
Install a C30 release
```

```
h, help
```

```
p <id>, part of disk to install to, 1 or 2
```

2. Execute the following command:

```
shell> dd if=/dev/zero of=/dev/ataraid/d0 bsQ2 count=1
```

3. Execute the following:

```
/usr/os/bin/install
```

4. Reboot and re-run /usr/os/bin/install.

Upgrading from Version 2.1 and Greater

Newer versions of Version 2.1 and greater allow you to do a full copy of the Running Partition (RP) to an Upgrade Partition (UP) before actually upgrading your system software.

To do this:

1. Make sure you are connected to the console.
2. Reboot your system into single user mode. To do this, at the root prompt, enter:

```
init 1
```
3. Once the system boots into single user prompt, enter the following:

```
/usr/os/sbin/cos-copy-dist -p 2
```

This copies your entire RP disk contents into the UP. This is a total disk copy and everything on the RP is copied to UP, including the application configurations.
4. Once the copy is complete, enter the following:

```
/usr/os/bin/cos_toggle other
```
5. Reboot your system. Your system is booted into the UP.
6. Upgrade your system software or applications, as needed.
7. Reboot if necessary.

If all upgrades are working normally, you are now on the UP (partition set 2). If, however, your upgrades fail, your system fails to boot up, or crashes, then you must reboot and when you get the bootup choices for the kernel under Grub, select the Chains option. Alternatively, if you are able to get to the root prompt but still do not want to upgrade, enter the following:

```
/usr/os/bin/cos_toggle other
```

NOTE: To view the current partition, enter the following:

```
/usr/os/bin/cos_toggle
```

The default value is “vmlinuz-2.4.18-5” and indicates your original RP.

To list possible selections, enter the following:

```
/usr/os/bin/cos_toggle -l
```

The “other” value indicates the second part of the disk, which is your UP.

Then reboot system.

To go back to the original partition (RP) that was working properly, reboot the system.

Upgrading from Software to a UP While an RP is Operational (Rollback)

Newer versions than 2.1 and greater allow you to install the system software to a UP while an RP is operational. This is done using `/usr/os/sbin/install-cos`. Install-cos can install to either part 1 or 2 of the disk. You can run install-cos while the system is booted from the install server or the system is running off the disk.



CAUTION:

Caution: Reboot into the UP first, making sure the UP is working, then upgrade within the UP, leaving the good RP alone.

To install to the UP of your system while the system is running with the RP:

1. Enter the following command:

```
/usr/os/sbin/install-cos -p 2 <release directory>
```
2. Manually configure the UP identically to the RP (System configuration and applications).
3. Switch to the RP and upgrade the RP.
4. If upgrades work correctly you are done. If, however, the upgrades fail, reboot the system. By default the system boots with the functional UP.

3Com provides easy access to technical support information through a variety of services. This chapter describes these services.

Information contained in this chapter is correct at time of publication. For the most recent information, 3Com recommends that you access the 3Com Corporation World Wide Web site.

Online Technical Services

3Com offers worldwide product support 24 hours a day, 7days a week, through the following online systems:

- World Wide Web site
- 3Com Knowledgebase Web Services
- 3Com FTP site

World Wide Web Site

To access the latest networking information on the 3Com Corporation World Wide Web site, enter this URL into your Internet browser:

<http://www.3com.com/>

This service provides access to online support information such as technical documentation and software library, as well as support options that range from technical education to maintenance and professional services.

3Com Knowledgebase Web Services

The 3Com Knowledgebase is a database of technical information to help you install, upgrade, configure, or support 3Com products. The Knowledgebase is updated daily with technical information discovered by 3Com technical support engineers. This complimentary service, which is available 24 hours a day, 7 days a week to 3Com customers and partners, is located on the 3Com Corporation World Wide Web site at:

http://www.knowledgebase_3com.com/

3Com FTP Site

Download drivers, patches, software, and MIBs across the Internet from the 3Com public FTP site. This service is available 24 hours a day, 7 days a week.

To connect to the 3Com FTP site, enter the following information into your FTP client:

Hostname: ftp.3com.com

Username: anonymous

Password: <your Internet e-mail address>

Note: You do not need a user name and password with Web browser software such as Netscape Navigator and Internet Explorer.

Support from Your Network Supplier

If you require additional assistance, contact your network supplier. Many suppliers are authorized 3Com service partners who are qualified to provide a variety of services, including network planning, installation, hardware maintenance, application training, and support services.

When you contact your network supplier for assistance, have the following information ready:

- Product model name, part number, and serial number
- A list of system hardware and software, including revision levels
- Diagnostic error messages
- Details about recent configuration changes, if applicable

If you are unable to contact your network supplier, see the following section on how to contact 3Com.

Support from 3Com

If you are unable to obtain assistance from the 3Com online technical resources or from your network supplier, 3Com offers email and telephone technical support services. To find out more about your support options, email or call the 3Com technical support services at the location nearest you.

Email Support

Some 3Com regions offer an email support service. To access this service for your region, use the appropriate URL or email address from the list below.

Asia, Pacific Rim

From this region, email: apr_technical_support@3com.com

Europe, Middle East and Africa

Enter the URL: <http://emea.3com.com/support/email.html>

Latin America

Spanish speakers, enter the URL: <http://lat.3com.com/lat/support/form.html>

Portuguese speakers, enter the URL: <http://lat.3com.com/br/support/form.html>

English speakers, email: lat_support_anc@3com.com

Telephone Support

When you contact 3Com for assistance, have the following information ready:

- Product model name, part number, and serial number
- A list of system hardware and software, including revision levels
- Diagnostic error messages
- Details about recent configuration changes, if applicable

The following table provides a list of worldwide technical telephone support numbers. These numbers are correct at the time of publication. Refer to the 3Com Web site for updated information.

Telephone Support Numbers

| Country | Telephone Number | Country | Telephone Number |
|--------------------------|---------------------|---------------------------------------|--------------------------|
| Asia, Pacific Rim | 1 800 678 515 | Europe, Middle East and Africa | |
| Australia | +61 2 9424 5179 or | | |
| India | 000800 6501111 | From anywhere in these regions, call: | +44 (0)1442 435529 phone |
| Indonesia | 001 803 61 009 | | |
| Malaysia | 1800 801 777 | | |
| New Zealand | 0800 446 398 | Austria | 01 7956 7124 |
| Pakistan | +61 2 9937 5083 | Belgium (Flemish) | 070 700 000 |
| Philippines | 1235 61 266 2602 or | Belgium (French) | 070 700 770 |
| | +61 2 9937 5076 | Denmark | 7010 7289 |
| | 800 6161 463 | Finland | 01080 2783 |
| Singapore | 00798 611 2230 or | France | 0825 809 622 |
| S. Korea | 02 3455 6455 | Germany | 01805 404 747 |
| | 0080 611 261 | Hungary | 06800 14466 |
| | 001 800 611 2000 | Ireland | 1800 509359 |
| Taiwan | | Israel | 1800 943 2632 |
| Thailand | | Italy | 199 161346 |
| | | Luxembourg | 800 29880 |
| | | Netherlands | 0900 777 7737 |
| | | Norway | 815 33 047 |
| | | Poland | 00800 441 1357 |
| | | Portugal | 707 200 123 |
| | | South Africa | 0800 991196 |
| | | Spain | 9 021 60455 |
| | | Sweden | 07711 14453 |
| | | Switzerland | 08488 50112 |
| | | U.K. | 0870 241 3901 |

| Country | Telephone Number | Country | Telephone Number |
|----------------------|------------------|----------------------|------------------|
| Latin America | | North America | 1 800 876 3266 |
| From the Caribbean, | 1 800 988 2112 | | |
| Central and South | 0 810 444 3COM | | |
| America, call: | 1 800 998 2112 | | |
| Antigua | 1 800 998 2112 | | |
| Argentina | 1 800 998 2112 | | |
| Aruba | 52 5 201 0010 | | |
| Bahamas | 1 800 998 2112 | | |
| Barbados | 1 800 998 2112 | | |
| Belize | 0800 13 3COM | | |
| Bermuda | 1 800 998 2112 | | |
| Bonaire | AT&T +800 998 | | |
| Brazil | 112 | | |
| Cayman | AT&T +800 998 | | |
| Chile | 2112 | | |
| Colombia | AT&T +800 998 | | |
| Costa Rica | 2112 | | |
| Curacao | 1 800 998 2112 | | |
| Ecuador | AT&T +800 998 | | |
| Dominican Republic | 2112 | | |
| Guatemala | AT&T +800 998 | | |
| Haiti | 2112 | | |
| Honduras | AT&T +800 998 | | |
| Jamaica | 2112 | | |
| Martinique | 57 1 657 0888 | | |
| Mexico | AT&T +800 998 | | |
| Nicaragua | 2112 | | |
| Panama | 1 800 998 2112 | | |
| Paraguay | 571 657 0888 | | |
| Peru | 01 800 849CARE | | |
| Puerto Rico | AT&T +800 998 | | |
| Salvador | 2112 | | |
| Trinidad and Tobago | AT&T +800 998 | | |
| Uruguay | 2112 | | |
| Venezuela | 54 11 4894 1888 | | |
| Virgin Islands | AT&T +800 998 | | |
| | 2112 | | |
| | 1 800 998 2112 | | |
| | AT&T +800 998 | | |
| | 2112 | | |
| | 1 800 998 2112 | | |
| | AT&T +800 998 | | |
| | 2112 | | |
| | AT&T +800 998 | | |
| | 2112 | | |
| | 57 1 657 0888 | | |

Returning Products for Repair

Before you send a product directly to 3Com for repair, you must first obtain an authorization number. Products sent to 3Com without authorization numbers will be returned to the sender unopened, at the sender's expense.

You can obtain an authorization number (called an RMA) by entering the following URL into your Internet browser:

http://www.3com.com/support/en_US/repair


Alternatively, you can obtain an RMA by calling or faxing one of the numbers in the following table:

Fax Numbers for return authorization numbers

| Country | Telephone Number | Fax Number |
|---------------------------------------|--------------------|--------------------------------|
| Asia, Pacific Rim | +65 543 6500 | +65 543 6348 |
| Europe, Middle East and Africa | +44 (0)1442 435529 | |
| | 01 7956 7124 | |
| Austria | 070 700 000 | |
| Belgium (Flemish) | 070 700 770 | |
| Belgium (French) | 7010 7289 | |
| Denmark | 01080 2783 | |
| Finland | 0825 809 622 | |
| France | 01805 404 747 | |
| Germany | 06800 14466 | |
| Hungary | 1800 509359 | |
| Ireland | 1800 943 2632 | |
| Israel | 199 161346 | |
| Italy | 800 29880 | |
| Luxembourg | 0900 777 7737 | |
| Netherlands | 815 33 047 | |
| Norway | 00800 441 1357 | |
| Poland | 707 200 123 | |
| Portugal | 0800 991196 | |
| South Africa | 9 021 60455 | |
| Spain | 07711 14453 | |
| Sweden | 08488 50112 | |
| Switzerland | 0870 241 3901 | |
| U.K. | | |
| USA and Canada | 1 800 876 3266 | 1 508 323 6061 (not toll free) |

| Country | Telephone Number | Fax Number |
|----------------------|--------------------|------------|
| Latin America | | |
| Antigua | 1-800-988-2112 | |
| Argentina | 0-810-444-3COM | |
| Aruba | 1-800-998-2112 | |
| Bahamas | 1-800-998-2112 | |
| Barbados | 1-800-998-2112 | |
| Belize | 52-5-201-0010 | |
| Bermuda | 1-800-998-2112 | |
| Bonaire | 1-800-998-2112 | |
| Brazil | 0800-13-3COM | |
| Cayman | 1-800-998-2112 | |
| Chile | AT&T +800-998-2112 | |
| Colombia | AT&T +800-998-2112 | |
| Costa Rica | AT&T +800-998-2112 | |
| Curacao | 1-800-998-2112 | |
| Ecuador | AT&T +800-998-2112 | |
| Dominican Republic | AT&T +800-998-2112 | |
| Guatemala | AT&T +800-998-2112 | |
| Haiti | 57-1-657-0888 | |
| Honduras | AT&T +800-998-2112 | |
| Jamaica | 1-800-998-2112 | |
| Martinique | 57-1-657-0888 | |
| Mexico | 01-800-849CARE | |
| Nicaragua | AT&T +800-998-2112 | |
| Panama | AT&T +800-998-2112 | |
| Paraguay | 54-11-4894-1888 | |
| Peru | AT&T +800-998-2112 | |
| Puerto Rico | 1-800-998-2112 | |
| Salvador | AT&T +800-998-2112 | |
| Trinidad and Tobago | 1-800-998-2112 | |
| Uruguay | AT&T +800-998-2112 | |
| Venezuela | AT&T +800-998-2112 | |
| Virgin Islands | 57-1-657-0888 | |

Technical Specifications



This appendix lists the physical, environmental, and power characteristics of the 3COM Security Switch 6200.

Physical Characteristics

Size (Inches): 3.5 H x 17.5 W x 25.5 D
Weight: approximately 32 lbs

Environmental Characteristics

Operating Temperature: 0 to +40 degrees C
Storage Temperature: -20 to +65 degrees C
Relative Humidity: 10 to 95 percent, non-conducting
Operating Altitude: 0 to 10,000 feet above sea level

Power Characteristics


Power: 100 to 240 VAC, 350W

Connector Pin Assignments

B

This appendix describes the craft port pin assignments:

The Craft port, located on the front of the system, uses a DB- 9 connector with the following pin identifications and associated signals.

| DB-9 Connector | Pin Number | Signal |
|---|------------|---------------|
|  | 1 | No Connection |
| | 2 | TDX |
| | 3 | RXD |
| | 4 | DSR |
| | 5 | GND |
| | 6 | DTR |
| | 7 | CTS |
| | 8 | RTS |
| | 9 | No Connection |

This appendix provides the following compliance statements:

- Regulatory Standards Compliance
- Radio Frequency Interference
- VCCI Statement

Regulatory Standards Compliance

The following regulatory agencies have approved the 3COM Security Switch 6200 and have found it to be fully compliant with their environmental, safety, and emissions standards.

CE marking for the EEA (European Economic Area)

- Low Voltage Directive 73/23/EEC
- EMC Directive 89/336/EEC

Safety

- IEC 60950
- UL 60950
- CSA C22.2 No. 60950

Factory Approvals

- UL/CSA

EMI Compliance

Radio Frequency Interference

NOTE

In accordance with FCC Part 15 Subpart B requirements, changes or modifications made to this equipment not expressly approved by 3COM Corporation could void the user's authority to operate this equipment.

The 3COM Security Switch 6200 is designed for Class A use only. Do not attempt to use this equipment in a domestic environment, which requires Class B distinction. The system may cause interference with domestic products.

This equipment produces electromagnetic energy at radio frequencies and, if not installed and operated in accordance with 3COM instructions, as contained in this document, could cause interference to radio communications and/or interfere with the operation of other RF devices. This equipment has been tested and found to comply with the limits for a Class A Computing Device pursuant to Subpart B of Part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area may cause interference. Should this occur, the user may be required to discontinue operation of the equipment, or take other such measures as may be adequate to rectify the condition at the user's expense.

VCCI Statement V-3/2000.04

This is a Class A product based on the standards of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

Other EMI Approvals

- EN 55022
- AS/NZS 3548:95
- BSMI CNS 13438 Class A

Immunity Compliance

The system meets all EN 55024 immunity testing.